

FPE - FPM

F001	FRONT – SIGHT	
F002	FRONT – SIGHT SCREW	
F003	FRONT – SIGHT HOLDER SCREW	
F004	FRONT – SIGHT HOLDER SLEDGE	
F005/E	COMPENSATOR BODY	
F005/EC	COMPLETE COMPENSATOR	
F005/M	COMPENSATOR BODY	
F005/MC	COMPLETE COMPENSATOR	
F006	COMPENSATOR CONE	
F007	COMPENSATOR CONE FIXING SCREW	
F008	BARREL	
F009	CONNECTING ROD SPRING	
F010	CONNECTING ROD	
F011	SLIDE	
F012	ARM LEVER	
F013	CONNECTING ROD LOCKING PIN	
F014	ARM LEVER LOCKING PIN	
F015	CONNECTING ROD LOCKING PIN	
F016	BOLT SHOCK ABSORBER	
F017	FIRING PIN PUSHER LOCKING PIN	
F018	FIRING PIN	
F019	FIRING PIN SPRING	
F020	FIRING PIN SPRING PUSHER	
F021	FIRING PIN HOOK – SEAR PIN	
F022	EXTRACTOR	
F023	EXTRACTOR LOCKING SCREW	
F024	REAR – SIGHT ELEVATION SPRING	
F025	COMPLETE REAR – SIGHT	
F025/01	ADJUSTABLE REAR – SIGHT BLADE	
F025/02	ADJUST.REAR – SIGHT BLADE LOCK. SCREW	
F025/03	REAR – SIGHT BLADE SUPPORT	
F025/04	REAR – SIGHT ADJ. SCREW	
F025/05	REAR – SIGHT PIN	
F025/06	REAR – SIGHT ELEVATOR SPRING	
F025/07	REAR – SIGHT BALL	
F025/08	REAR – SIGHT BODY	
F025/09	REAR – SIGHT PLATE SPRING	
F025/10	REAR – SIGHT ELEV. CUN.	
F025/11	STOP SCREW	
F025/12	ELASTIC RING	
F025/C	COMPLETE REAR – SIGHT WITH ADJUST.BLADE	
F026	SLIDING RULE STOP BOLT	
F027	SLIDING RULE BALL	
F028	SLIDING RULE BALL SPRING	
F029	SLIDING RULE END RUN PIN	
F030	SLIDING RULE END RUN PIN SPRING	
F031	PUSHING SCREW	
F032	SPRING	
F033	ARM LEVER BALL	
F034	2ND STAGE INTERNAL SCREW	
F035	2ND STAGE SPRING	
F036	2ND STAGE BALL	
F037	2ND STAGE EXTERNAL SCREW	
F037/C	COMPLETE 2ND STAGE SCREW	
F038/E	FIRING PIN ENGAGEMENT SEAR	
F038/M	FIRING PIN ENGAGEMENT SEAR	
F039	FIRING PIN ENGAGEMENT SEAR SPRING	
F040	REAR – SIGHT LOCKING PIN	
F041	CONTACT	
F042	CONTACT LOCK. SCREW	
F043/E	PISTOL FRAME FPE	
F043/M	PISTOL FRAME FPM	

F044	SCREW LOCKING BARREL	
F045/E	TRIGGER WEIGHT SPRING	
F045/M	TRIGGER WEIGHT SPRING	
F046/E	TRIGGER WEIGHT SCREW	
F046/M	TRIGGER WEIGHT SCREW	
F047/E	DISCONNECTOR	
F047/M	DISCONNECTOR	
F048/E	DISCONNECTOR LOCKING PIN	
F048/M	DISCONNECTOR LOCKING PIN	
F049	1ST STAGE ADJ. RUNN. SCREW	
F050	TRIGGER-STOP	
F051	TRIGGER	
F052	TRIGGER LOCKING SCREW	
F053	TRIGGER ROD	
F054	TRIGGER ROD LOCKING SCREW	
F055	TRIGGER SPACER	
F056	THREADED BUSH	
F057/E	STECKER	
F057/M	STECKER	
F058/E	STECKER SPRING	
F058/M	STECKER SPRING	
F059	STECKER SCREW	
F060	STECKER NYLON INSERT	
F061	CONTACT SPRING LOCK. SCREW	
F062	CONTAC SPRING	
F063	ELECTRONIC TRIGGER	
F064	ELECTRONIC TRIGGER FIXING SCREW	
F065	COMPLETE POWER SWITCH	
F066	WASHER	
F067	SWITH FIXING SCREW	
F068	GRIP LOCKING SCREW	
F069	PALM REST LOCKING PIN	
F070	PALM REST	
F071	PALM REST LOCKING SCREW	
F072/E1	SMALL ADJUSTABLE RIGHT – HAND GRIP	
F072/E2	MEDIUM ADJUSTABLE RIGHT – HAND GRIP	
F072/E3	ADJUSTABLE LEFT – HAND GRIP	
F072/M1	SMALL ADJUSTABLE RIGHT – HAND GRIP	
F072/M2	MEDIUM ADJUSTABLE RIGHT – HAND GRIP	
F072/M3	ADJUSTABLE LEFT – HAND GRIP	
F087	COMPENSATOR FIXING SCREW	
F073	WASHER	
F074	DISCONNECTOR SPRING	
F075	COUNTERHOOK – SEAR	
F076	HOOK – SEAR	
F077	HOOK SEAR PIN	
F078	COUNTERHOOK – SEAR PIN	
F079	HAMMER	
F080	HAMMER SPRING	
F081	TRIGGER WEIGHT BEND SPRING	
F082	BEND SPRING PIN	
F083	HAMMER SPRING PIN	
F084	ENG. SEAR RUN ADJ. SCREW	
F085	PLATE	
F086	PLATE SCREW	