

# GPE

1100	COUNTER-HAMMER PIN	
1101	COUNTER-HAMMER	
1102	HAMMER PIN	
1103	HAMMER	
1103/M	HAMMER GPE MECHANICAL	
1104	HAMMER SPRING GUIDE	
1104/M	HAMMER SPRING GUIDE GPE MECHANICAL	
1105	HAMMER GUIDE PIN	
1105/M	HAMMER GUIDE PIN GPE MECHANICAL	
1106	BOLT GUIDE PIN	
1107	TRIGGER STOP SCREW	
1107/M	TRIGGER STOP SCREW MECHANICAL	
1108	TRIGGER WEIGHT SPRING	
1109	TRIGGER WEIGHT SCREW	
1110	TRIGGER LOCKING SCREW	
1111	DISCONNECTOR ENGAG. SCREW	
1111/M	DISCONNECTOR ENGAG. SCREW	
1112	DISCONNECTOR	
1112/1	COMPLETE DISCONNECTOR	
1112/1M	COMPLETE DISCONNECTOR	
1112/M	DISCONNECTOR	
1113	DISCONNECTOR PIN	
1114	TRIGGER GPE	
1114/M	TRIGGER GPE	
1115	FRONT SHOCK ABSORBER	
1116	FRONT INSERT LOCK. SCREW	
1117	BACK INSERT LOCK. SCREW	
1118	INSERT ERGAL	
1119	BARREL GPE	
1120	COUNTER-WEIGHT LOCKING PIN	
1121	COUNTER-WEIGHT	
1121/M	COUNTER-WEIGHT BLACK	
1121/1	COMPLETE COUNTER-WEIGHT	
1121/2	COUNTER-WEIGHT BODY	
1121/3	COUNT. WEIGHT WEIGHT	
1121/3T	COUNT. WEIGHT RIES WEIGHT TUNGSTENO Ø 8 mm (each)	
1121/4	COUNT. WEIGHT SPRING	
1121/5	COUNT. WEIGHT PLATE	
1121/6	COUNTERWEIGHT PLATE SCREW	
1121/7	COUNTER-WEIGHT INF.SPACER	
1121/8	WASHER	
1121/9	C.W. LOCKING SCREW	
1121/10	STABILIZER	
1122	FRONT - SIGHT	
1123	FRONT - SIGHT SCREW	
1124	COUNTER-WEIGHT LOCKING SCREW	
1125	FIRING - PIN LOCKING PIN	
1126	EXTRACTOR LOCKING PIN	
1127	BOLT FRAME	
1127/1	COMPLETE BOLT	
1128	EXTRACTOR	
1129	EXTRACTOR SPRING	
1130	BOLT RECOIL SPRING	
1131	FIRING PIN SPRING	
1132	FIRING PIN	
1133	RETURN SPRING GUIDE	
1134	BOLT CATCH LOCKING PIN	
1135	BOLT CATCH	
1136	BOTTON STOP BOLT SPRING	
1137	COMPLETE MAGAZINE	
1137/1	MAGAZINE BODY	
1137/2	MAGAZINE ELEVATOR	

1137/3	MAGAZINE SPRING	
1137/4	MAGAZINE PLATE	
1137/5	MAGAZINE BASE	
1137/6	MAGAZINE BOTTON	
1137/7	MAGAZINE SHORT GEAR	
1138	MAGAZINE CATCH LOCKING PIN	
1139	MAGAZINE CATCH	
1140	MAGAZINE CATCH SPRING	
1141	HAMMER STOP PIN / FIX.TRIGGER	
1142	GRIP LOCKING PIN	
1143	GRIP LOCKING SCREW	
1144	POWER SWITCH	
1145	BATTERY	
1146	SWITH FIXING SCREW	
1147	COUNTER-HAMMER SPRING	
1148	COMPLETE REAR – SIGHT	
1148/1	ELASTIC RING	
1148/2	REAR – SIGHT BLADE SUPPORT	
1148/3	REAR – SIGHT ADJ. SCREW	
1148/4	REAR – SIGHT PIN	
1148/5	REAR – SIGHT ELEVATOR SPRING	
1148/6	REAR – SIGHT BALL	
1148/7	REAR – SIGHT BODY	
1148/8	REAR – SIGHT PLATE SPRING	
1148/9	REAR – SIGHT ADJ. CONE	
1148/10	ADJUSTABLE REAR – SIGHT BLADE	
1148/11	ADJUST.REAR – SIGHT BLADE LOCK. SCREW	
1148/12	STOP SCREW	
1149	REAR – SIGHT LOCKING PIN	
1150	REAR-S. EXTENSION GPE	
1151	HAMMER STOP SPRING	
1151/M	HAMMER STOP SPRING	
1152	HAMMER SPRING	
1152/M	HAMMER SPRING	
1153	ELECTRONIC TRIGGER	
1154	BACK SHOCK ABSORBER	
1155/1	SMALL RIGHT – HAND GRIP GPE	
1155/1M	SMALL RIGHT - HAND GRIP GPE MECH	
1155/2	MEDIUM RIGHT – HAND GRIP GPE	
1155/2M	MEDIUM RIGHT – HAND GRIP GPE MECH	
1155/3	LARGE RIGHT – HAND GRIP GPE	
1155/3M	LARGE RIGHT – HAND GRIP GPE MECH	
1155/4	SMALL LEFT – HAND GRIP GPE	
1155/4M	SMALL LEFT – HAND GRIP GPE MECH	
1155/5	MEDIUM LEFT – HAND GRIP GPE	
1155/5M	MEDIUM LEFT – HAND GRIP GPE MECH	
1155/6	LARGE LEFT – HAND GRIP GPE	
1155/6M	LARGE LEFT – HAND GRIP GPE MECH	
1156	PISTOL FRAME	
1156/M	PISTOL FRAME	
1157	EXTENSION LOCKING PIN	
1158	EXTENSION LOCKING SCREW	
1159	REAR – SIGHT ADJ. PIN	
1160	ELECTRONIC TRIGGER FIX.SCREW	
1160/M	MECHANICAL TRIGGER FIX.SCREW	
1161/M	PISTON SCREW	
1162/M	HOOK – SEAR SPRING	
1163/M	SEAR ENGAGEMENT SCREW	
1164/M	TRIGGER WEIGHT ADJ. SCREW	
1165/1M	COMP. TRIGGER MECHANISM	
1165/M	TRIGGER MECHANISM BODY	
1166/M	HOOK SEAR PIN	
1167/M	HOOK – SEAR	
1168/M	PISTON SPRING	

1169/M	PISTON	
1170/M	DISCONNECTOR SCREW	
1171/M	DISCONNECTOR SPRING	
1172/M	DISCONNECTOR LEVER	